



## Accessories



**10-Pin Split Cable TP240212** Connect your host adapter or protocol analyzer to your target with individual flying leads.



**10-Pin Grabber Clip Split Cable TP240411** Connect your host adapter or protocol analyzer to your target with individual flying leads.



**HDMI DDC Breakout Cable TP240710** 2m HDMI cable with DDC breakout header

**DVI DDC Breakout Cable TP240810** 2m DVI cable with DDC breakout header

**VGA DDC Breakout Cable TP240910** 2m VGA cable with DDC breakout header




**CAN Split Cable TP360410** 1 ft CAN DB9 Split Cable



**CAN Terminator TP360310** DB9-Male CAN Terminator



**OTG Mini-Plug Cable Set TP320610** Mini USB adapter cables for the Beagle USB 480 Protocol Analyzer or the Beagle USB 12 Protocol Analyzer.



**Digital I/O Cable with Grabber Clips TP320710** Provides grabber clips to help connect the digital IO interface of the Beagle USB 480 Protocol Analyzer to external logic




**USB 2.0 5-port PCI Card TP320810** Provides an additional USB 2.0 host controller for your desktop computer.



**USB Extension Cable TP320310** Connect USB devices with captive USB-A connectors quickly and easily to the Beagle USB Protocol Analyzers.



**USB A-B Cable 1 ft - 5 Pack TP321110** 5 pack of 1 foot USB A-B cables



**SMA M/M Cable 2 ft TP321510** SMA cable for digital input or output on the Beagle USB 5000 SuperSpeed Protocol Analyzer



**HDMI M/M Cable 3 ft TP322310** HDMI cable for synchronizing multiple Beagle USB 5000 v2 SuperSpeed Protocol Analyzer