



Accessories



10-Pin Split Cable TP240212 Connect your host adapter or protocol analyzer to your target with individual flying leads.



10-Pin Grabber Clip Split Cable TP240411 Connect your host adapter or protocol analyzer to your target with individual flying leads.



HDMI DDC Breakout Cable TP240710 2m HDMI cable with DDC breakout header

DVI DDC Breakout Cable TP240810 2m DVI cable with DDC breakout header

VGA DDC Breakout Cable TP240910 2m VGA cable with DDC breakout header




CAN Split Cable TP360410 1 ft CAN DB9 Split Cable



CAN Terminator TP360310 DB9-Male CAN Terminator



OTG Mini-Plug Cable Set TP320610 Mini USB adapter cables for the Beagle USB 480 Protocol Analyzer or the Beagle USB 12 Protocol Analyzer.



Digital I/O Cable with Grabber Clips TP320710 Provides grabber clips to help connect the digital IO interface of the Beagle USB 480 Protocol Analyzer to external logic




USB 2.0 5-port PCI Card TP320810 Provides an additional USB 2.0 host controller for your desktop computer.



USB Extension Cable TP320310 Connect USB devices with captive USB-A connectors quickly and easily to the Beagle USB Protocol Analyzers.



USB A-B Cable 1 ft - 5 Pack TP321110 5 pack of 1 foot USB A-B cables



SMA M/M Cable 2 ft TP321510 SMA cable for digital input or output on the Beagle USB 5000 SuperSpeed Protocol Analyzer



HDMI M/M Cable 3 ft TP322310 HDMI cable for synchronizing multiple Beagle USB 5000 v2 SuperSpeed Protocol Analyzer